

 \rightarrow

-

Quick User Guide

DB91-TX

Compact IP Audio Encoder

BEFORE YOU USE THIS PRODUCT

In order to be able to enjoy all the benefits of owning your new DEVA product, please verify first that the latest software and firmware release were installed.

Visit <u>www.devabroadcast.com/downloads</u> for the most recent software and firmware downloads, prior the installation.



DEVA Broadcast Limited is an ISO 9001:2015 certified company.

This Quick user guide will make the installation of **DB91-TX** quick and easy. Applying these principles, you can simplify the process and save yourself extra time and effort. For more information about the Safety precautions and the Operating environment recommendations please refer to the User Manual.

OTED 4	Connection	
SIEP 1	Connection	

- 1. The encoder has to be connected to the local network or Internet by cable with RJ-45 connector;
- 2. As only one input at a time can be managed by the encoder, please select the preferred signal source input either analog or digital one:
- For Analog audio use a cable that ends with two standard RCA jacks to connect the analog signal source to the analog audio inputs of DB91-TX;
- For Digital audio use a cable that ends with standard RCA jack to connect the S/PDIF signal source to the digital audio input of DB91-TX;
- 3. Connect the device to the power supply.

DB91-TX is controlled trough a build in WEB Server and a standard web browser can be used to monitor its status or to make some adjustments.

To operate the device you need to know its IP Address. In case you are not aware of it, you can hear it through the headphones when you turn on the the device. Alternatively, use the Network discovery feature at Local networks (for reference see Step 3).

Network discovery is a network setting that defines whether your computer can see (find) other computers and devices on the network and whether other computers on the network can see your computer. By default, Windows Firewall blocks network discovery but you can enable it.

If you have already enabled this function on your computer just open a new Explorer bar and click on (1). The device must be displayed.

- Open Advanced sharing settings by clicking the Start button, and then on "Control Panel". In the search box, type "network", click "Network and Sharing Center", and then, in the left pane click "Change advanced sharing settings";
- 2. Select your current network profile;
- 3. Click **Turn on network discovery**, and then click Save changes. If you're prompted for an administrator password or confirmation, type the password or provide confirmation.
- 4. To access the device open a new Explorer bar and click on (1). If you have successfully enabled the network discovery option, the device will be displayed. Double click on (2) will open a new WEB browser window requiring username and password. Default values being -Username: user or admin, Password: pass.



N: Digital (Main Di	ligital)	27 May 2016 Uptime: Session: 11:13:17 0d 02:05:29 co	Lo
Lippits Digital 5.7 9 5.4 5 9 5 9 10 10 10 20 50	Analog 77.2 76.6 790 712 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Stors Status Remote Peer Codec Streaming 192.168.20.78:8001 PCM Streaming 192.168.20.152:5004 MP3	Sta In Enc IP Ge Net

A successful log-in in the WEB Interface will look like this:

Upon opening the WEB interface, the main Status window will appear. The page contains information on the device's current status - the LED bar-graph representation of the left and right Digital and Analog audio levels in dBFS, as well as the Active connections - Type, Status, Remote Peer and Codec.

At the top of the control window is placed a constant section, containing information about the input in use, Date/Time and session timeout.

The DB91-TX provides you with a protected access to the device settings. Upon pressing the Settings button, a window requiring username and password will appear.

To make the necessary adjustments to the device log in as ADMINISTRATOR. This will give you full control over the settings. The default values beingusername: *admin*, password: *pass*);

I: Digital (Main Digital)	1		27 May 2016 Uptime 11:12:22 0d 02:04	e: Session: 1:33:	
Inputs Digital A	Active connect	tons	Remote Deer	Contar	
-2.0 -2.0 -77.1	-76.8 RTP Sender	Streaming	192.168.20.78:8001	PCM	
- 10 - - 20 - - 30 -	0	Streaming	192.168.20.152:5004	MP3	
	-70-				Status
					Setting
		Welcome!			
	Username:				
	Password:				
		Login			

```
STEP 5
```

Upon entering the device's settings, you will be able to apply needed adjustments to the Inputs, Encoding and IPAudio configuration of the DB91-TX.

DB91-TX - Compact IP Audio Encoder						
III: Digital (Main	Digital)			27 May 2016 Uptm 11:13:17 0d 02:0	e: Session: 5:29 co	Logout
- Inputs- Digital 5.7 9.5.4 5 4 10 - 12 - 22 - 25 - 2	Analog -77.2 0 -76.6 	- Active connections - Type RTP Sender RTP Sender	Status Streaming Streaming	Remote Peer 192.168.20.78:8001 192.168.20.152:5004	Codec PCM MP3	Status Input Encoding IP Audio General Network Other
FW: 0.1.1330 Serial: 91TX123	IP Address: 4 MAC:	192.168.20.185 (DHCP) 00:04:A3:91:CC:8E	Netmask: 2 Gateway: 1	55.255.255.0 DNS 1: 92.168.20.1 DNS 2:	192.168.20.5 0.0.0.0	

For further information on the available options and features, please refer to the User Manual which can be found on www.devabroadcast.com/downloads, and the accompanying CD.

Thank you for choosing DEVA!

Please refer to the User manual for detailed information on how to configure and explore your device.